## § 178.607 Cooperage test for bung-type wooden barrels.

- (a) Number of samples. One barrel is required for each different packaging.
- (b) Method of testing. Remove all hoops above the bilge of an empty barrel at least two days old.
- (c) Criteria for passing the test. A packaging passes the cooperage test only if the diameter of the cross-section of the upper part of the barrel does not increase by more than 10 percent.